

BLUE GATE

Inverter Load Chart



BG1000	4	2	1		1					1
BG2000	10	4	1	1	1					2
BG2800	10	5	2	1	1					2 to 4
BG3400	10	6	2	1	2	1	OR	1		2 to 4
BG5000	10	6	2	2	2	1	OR	1		4 to 8
BG6000	10	6	2	2	2	1	OR	1	1	4 to 8
BGS1500	6	2	1	1	1					2
BGS2500	10	4	2	1	1	1	OR	1		4
BGS3000	10	6	2	1	2	1	OR	1		4
BGS5000	10	6	2	2	2	1	OR	1	1	8
BGS7500	12	8	3	2	2	1		1	2	16
BGS10000	15	8	3	2	2	1		1	2	16
3.5KVA	10	4	2	1	2	1	OR	1		4 to 8
5.5KVA	10	4	2	1	2	1	OR	1	1	4 to 8

**Please note that the above chart is only a guideline; the actual may depend on the specification.